

Mellanox ETH

Upgrade firmwaru karty

Zjisteni part numberu a verze firmwaru u Mellanox karet. Potrebujeme mit nainstalovany balicek mstflint

```
# ethtool -i ens4f0np0
driver: mlx5_core
version: 5.5-1.0.3
firmware-version: 14.27.1016 (MT_2420110004)
expansion-rom-version:
bus-info: 0000:10:00.0
supports-statistics: yes
supports-test: yes
supports-eeprom-access: no
supports-register-dump: no
supports-priv-flags: yes

# lspci | grep Mella
10:00.0 Ethernet controller: Mellanox Technologies MT27710 Family
[ConnectX-4 Lx]
10:00.1 Ethernet controller: Mellanox Technologies MT27710 Family
[ConnectX-4 Lx]
81:00.0 Ethernet controller: Mellanox Technologies MT27710 Family
[ConnectX-4 Lx]
81:00.1 Ethernet controller: Mellanox Technologies MT27710 Family
[ConnectX-4 Lx]

# lspci -vv -s 10:00.0 | grep "Part number" -A 3
      [PN] Part number: MCX4121A-XCAT
      [EC] Engineering changes: AJ
      [SN] Serial number: MT2031J10949
      [V0] Vendor specific: PCIeGen3 x8

# mstflint -d 10:00.0 q
Image type:          FS3
FW Version:         14.27.1016
FW Release Date:    27.2.2020
Product Version:    14.27.1016
Rom Info:           type=UEFI version=14.20.19 cpu=AMD64,AARCH64
                   type=PXE version=3.5.901 cpu=AMD64
Description:        UID                               GuidNumber
Base GUID:          0c42a10300eabd04          4
Base MAC:           0c42a1eabd04          4
Image VSD:          N/A
Device VSD:         N/A
PSID:              MT_2420110004
```

Security Attributes: N/A

Upgrade FW

Podle part number a PSID vybereme konkretni verzi FW na webu NVIDIA. V našem případě je to **Part number: MCX4121A-XCAT** a **PSID: MT_2420110004**. Vybereme tedy nasledujici firmware:

ConnectX-4 Lx Ethernet Firmware Download Center

Current Versions
Archive Versions
START OVER

Version (Current)	OPN	PSID	Download/Documentation
14.32.1900	MCX4411A-ACAN MCX4131A-GCAT MCX4131A-BCAT MCX4121A-XCHT MCX4121A-XCAS MCX4121A-ACUT MCX4121A-ACHT	MT_2420110004	<p>ConnectX4Lx: fw-ConnectX4Lx-rel-14_32_1900-MCX4121A-XCA_Ax-UEFI-14.25.17-FlexBoot-3.6.502</p> <p>MD5SUM: 06adda309f41dae265387470cae6c880</p> <p>SHA256: bb86ede3116089043595e3b81ac4d54bbfe7f937090fec9a8d3c9db08164effc</p> <p>Release Date: 03-September-2024</p> <p>Documentation: Release Notes EULA</p>

Po stazeni je dobre overit md5 prikazem md5sum a porovnat, jestli sedí s checksumem uvedeným na webu.

```
06adda309f41dae265387470cae6c880 fw-ConnectX4Lx-rel-14_32_1900-MCX4121A-XCA_Ax-UEFI-14.25.17-FlexBoot-3.6.502.bin.zip
```

A nyní můžeme po rozbalení přejít k upgradu FW:

```
# mstflint -d 10:00.0 -i fw-ConnectX4Lx-rel-14_32_1900-MCX4121A-XCA_Ax-UEFI-14.25.17-FlexBoot-3.6.502.bin burn
```

```
Current FW version on flash: 14.27.1016
New FW version: 14.32.1900
```

```
FSMST_INITIALIZE - OK
Writing Boot image component - OK
-I- To load new FW run mstfwreset or reboot machine.
```

```
# mstflint -d 10:00.0 v
```

```
FS3 failsafe image
```

```
/0x00800038-0x00801e8b (0x001e54)/ (BOOT2) - OK
```

```

/0x00802000-0x0080201f (0x000020)/ (ITOC_HEADER) - OK
/0x00804000-0x0081472b (0x01072c)/ (IRON_PREP_CODE) - OK
/0x00815000-0x008150ff (0x000100)/ (FS3_RESET_INFO) - OK
/0x00816000-0x00816bff (0x000c00)/ (FW_MAIN_CFG) - OK
/0x00817000-0x008174bf (0x0004c0)/ (FW_BOOT_CFG) - OK
/0x00818000-0x008195ff (0x001600)/ (HW_MAIN_CFG) - OK
/0x0081a000-0x0081a13f (0x000140)/ (HW_BOOT_CFG) - OK
/0x0081b000-0x0081dc7f (0x002c80)/ (PHY_UC_CONSTS) - OK
/0x0081e000-0x0081e13f (0x000140)/ (IMAGE_SIGNATURE_256) - OK
/0x0081f000-0x0081f8ff (0x000900)/ (PUBLIC_KEYS_2048) - OK
/0x00820000-0x0082008f (0x000090)/ (FORBIDDEN_VERSIONS) - OK
/0x00821000-0x0082123f (0x000240)/ (IMAGE_SIGNATURE_512) - OK
/0x00822000-0x008230ff (0x001100)/ (PUBLIC_KEYS_4096) - OK
/0x00824000-0x00873fff (0x050000)/ (FS4_PART_TYPE_PROGRAMMABLE_HW_FW) -

```

OK

```

/0x00874000-0x00925e27 (0x0b1e28)/ (ROM_CODE) - OK
/0x00926000-0x00935fff (0x010000)/ (CRDUMP_MASK_DATA) - OK
/0x00936000-0x009369ff (0x000a00)/ (PHY_UC_CMD) - OK
/0x00937000-0x0094091f (0x009920)/ (PHY_UC_CODE) - OK
/0x00941000-0x0096c457 (0x02b458)/ (PCI_CODE) - OK
/0x0096d000-0x00cbb8bf (0x34e8c0)/ (MAIN_CODE) - OK
/0x00cbc000-0x00cc9cbf (0x00dcc0)/ (PCIE_LINK_CODE) - OK
/0x00cca000-0x00ccae3f (0x000e40)/ (POST_IRON_BOOT_CODE) - OK
/0x00ccb000-0x00ccce0f (0x001e10)/ (UPGRADE_CODE) - OK
/0x00ccd000-0x00ccd3ff (0x000400)/ (IMAGE_INFO) - OK
/0x00ccd400-0x00ccdb6f (0x000770)/ (DBG_FW_INI) - OK
/0x00ccdb70-0x00ccdb77 (0x000008)/ (DBG_FW_PARAMS) - OK
/0x00fa0000-0x00faffff (0x010000)/ (NV_DATA) - CRC IGNORED
/0x00fb0000-0x00fbffff (0x010000)/ (NV_DATA) - CRC IGNORED
/0x00fc0000-0x00fcffff (0x010000)/ (FW_NV_LOG) - CRC IGNORED
/0x00fee000-0x00fee1ff (0x000200)/ (DEV_INFO) - OK
/0x00ff8000-0x00ff813f (0x000140)/ (MFG_INFO) - OK
/0x00ff8140-0x00ff81b7 (0x000078)/ (VPD_R0) - OK

```

-I- FW image verification succeeded. Image is bootable.

```
# mstflint -d 10:00.0 q full
```

```

Image type:          FS3
FW Version:          14.32.1900
FW Version(Running): 14.27.1016
FW Release Date:     25.8.2024
Part Number:         MCX4121A-XCA_Ax
Description:         ConnectX-4 Lx EN network interface card; 10GbE dual-
port SFP28; PCIe3.0 x8; ROHS R6
Product Version:     14.27.1016
Rom Info:            type=UEFI version=14.20.19 cpu=AMD64,AARCH64
                    type=PXE version=3.5.901 cpu=AMD64
Description:         UID                               GuidNumber
Base GUID:           0c42a10300eabd04                          4
Base MAC:            0c42a1eabd04                          4
Image VSD:           N/A

```

```
Device VSD:          N/A
PSID:               MT_2420110004
Security Attributes: N/A
Default Update Method: fw_ctrl
```

Nakonec provedeme reboot stroje.

```
Image type:          FS3
FW Version:          14.32.1900
FW Release Date:     25.8.2024
Product Version:     14.32.1900
Rom Info:            type=UEFI version=14.25.17 cpu=AMD64,AARCH64
                   type=PXE version=3.6.502 cpu=AMD64
Description:         UID                               GuidNumber
Base GUID:           0c42a10300eabd04                    4
Base MAC:            0c42a1eabd04                       4
Image VSD:           N/A
Device VSD:          N/A
PSID:               MT_2420110004
Security Attributes: N/A
```

Cerpano odtud:

- [Firmware Connect-X4](#)

Upgrade ovladacu v jadre

1. Ovladace je mozne stahnout z [teto stránky](#)
2. Doporučuje se stáhnout vždy zdrojový balíček pro příslušnou nejbližší verzi OS
3. Před instalací modulu jádra potřebujeme aktuální zdrojové kody spuštěného jádra systému. V debianu toho docílíme instalací balíčku **linux-headers-amd64**
4. Po rozbalení archivu do adresáře /usr/src spustíme příkaz `/install.pl --force-dkms`
5. Tímto způsobem zajistíme kompilaci kodulu pomocí dkms avygenerování příslušných instalačních balíčků, které se sami i nainstalují.
6. Po úspěšném dokončení restartujeme system.

Následně můžeme ověřit příkazem **ethtool** instalaci nového modulu jádra

```
# ethtool -i eth2
driver: mlx5_core
version: 5.8-6.0.4
firmware-version: 14.32.1900 (MT_2420110004)
expansion-rom-version:
bus-info: 0000:03:00.0
supports-statistics: yes
supports-test: yes
supports-eeprom-access: no
supports-register-dump: no
supports-priv-flags: yes
```

Instalace řes DKMS zajistí, že se modul překompiluje pro aktuální verzi kernelu v případě že v budoucnu dojde k upgradu jádra systému.

Po instalaci nových ovladačů bude potřeba asi doinstalovat znovu balíček mstflint, protože instalační skript preventivně před instalací nové verze modulu odinstaluje všechny stávající balíčky týkající se mellanox karet.

Odkazy

- [Firmware Download](#)
- [Ovladace MLNX_EN](#)

Prepnuti rezimu karty

Kartu lze prepnout mezi rezimem **InfiniBand** a **Ethernet** timto prikazem:

```
mstconfig -d 85:00.0 set LINK_TYPE_P2=2
```

- Nečíslovaný seznam **LINK_TYPE_P1** nebo **LINK_TYPE_P2** - vyber portu na karte
- parametr 1 = InifiniBand (hlasi se v systemu jako ibx), parametr 2 = ethernet

```
Device #1:
-----

Device type:    ConnectX4
Name:          N/A
Description:    N/A
Device:        85:00.0

Configurations:
LINK_TYPE_P2           Next Boot           New
                       IB(1)                ETH(2)

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```

Zobrazeni aktualniho nastaveni

```
<code> mstconfig -d 85:00.0 q | grep LINK
```

```
LINK_TYPE_P1           IB(1)
LINK_TYPE_P2           IB(1)
KEEP_ETH_LINK_UP_P1    True(1)
KEEP_IB_LINK_UP_P1     False(0)
KEEP_LINK_UP_ON_BOOT_P1 False(0)
KEEP_LINK_UP_ON_STANDBY_P1 False(0)
KEEP_ETH_LINK_UP_P2    True(1)
KEEP_IB_LINK_UP_P2     False(0)
KEEP_LINK_UP_ON_BOOT_P2 False(0)
```

KEEP_LINK_UP_ON_STANDBY_P2	False(0)
----------------------------	----------

new configurations. [16:25:16] 0 ;) root@gw-shiran:~# mstconfig -d 85:00.0 q | grep LINK

LINK_TYPE_P1	ETH(2)
LINK_TYPE_P2	ETH(2)
KEEP_ETH_LINK_UP_P1	True(1)
KEEP_IB_LINK_UP_P1	False(0)
KEEP_LINK_UP_ON_BOOT_P1	False(0)
KEEP_LINK_UP_ON_STANDBY_P1	False(0)
KEEP_ETH_LINK_UP_P2	True(1)
KEEP_IB_LINK_UP_P2	False(0)
KEEP_LINK_UP_ON_BOOT_P2	False(0)
KEEP_LINK_UP_ON_STANDBY_P2	False(0)

From:
<https://wiki.spoje.net/> - **SPOJE.NET**

Permanent link:
<https://wiki.spoje.net/doku.php/howto/hw/mellanox?rev=1762788596>

Last update: **2025/11/10 16:29**

